



# SPIRALFAST™

The Professionals Choice



**The fast, strong, easy way to join fence & trellis wire**

TEL +612 4335 1424

[info@spiralfast.com](mailto:info@spiralfast.com)

[www.spiralfast.com](http://www.spiralfast.com)

## The fast, strong, easy way to join fence & trellis wire

### FEATURES

Spiralfast is for permanent, electric fencing and trellising, ideal for vineyards, netting, orchards and greenhouse settings - wherever high-tensile wire is used

- Easily apply by hand, no special tools required
- Super-strong load to 700 kilos exceeds knots and most mechanical joiners
- Titanium coast ensures corrosive-free join
- Sustainable - retention | reuse | recycle
- 10 year guarantee, Australian made!

Apply once. Customers report original Spiralfast still in place after 20 years.

### ANOTHER HAPPY CUSTOMER...

“  
**Trigg Industries has been using Spiralfast wire joiners for years due to their strength and durability.**

**They don't break or damage wire like the mechanical joiners and are essential to making a quality wire join for our vineyard trellis and fences.**

**Highly recommend this product!**”



### SPECIFICATIONS

PRODUCT	COLOUR CODE	SIZE	TYPICAL APPLICATION	MAX WORKING LOAD
ST20	Green	1.8-2.0mm wire/gauge 14/15	Dripper lines, tomato trellises	350kg
ST25	Grey	2.5-2.8mm wire/gauge 11.5/12.5	Fence, netting and trellises	600kg
ST30	Blue	2.8-3.15mm wire/gauge 10/11.5	Fence, netting and trellises	700kg
ST40	Brown	4mm soft wire/gauge 8	Fence and easy knotting	300 kg

### INSTALLATION

**1**

Place the centre of the Spiralfast Joiner against the wire about 4cm (1.5 inches) from its end. Wrap one end of the joiner around the wire by hand.

Always wrap away from the centre following the direction of the spiral.

**2**

Poke the end of the second wire under the hump at the centre of the Joiner so that the ends of both wires pass under the hump and lock against each other.

**3**

**5cm or more**

**There should be 5cm (2 inches) of overlap at the centre.**

Wrap the other Spiralfast half around the second wire.

### TIPS

- Overlap both wires together as you put the Spiralfast flat section on top, before winding each side - this ensures the wires won't pull apart.
- Wear safety goggles and gloves when working with wire.

### Store details