



# COOKTOP CLEANER & PROTECTOR



Magic Cooktop Cleaner & Protector's non-scratch formula cleans and protects glass, induction and enamel cooktops. Making cleaning easier by leaving a protective film, helping protect against future marks.

Keeping glass and enamel cooktops clean of burnt-on food, oil, watermarks, and stains can be tricky. Magic Cooktop Cleaner & Protector is ideal for glass, enamel and induction cooktops. It is also great for removing soap scum from ceramic tiles and shower screens.

## FEATURES:

- ① Removes Baked on Grease & Grime
- ② Polishes Glass & Enamel Cooktops
- ③ Protects & Repels New Marks
- ④ Non-Scratch Formula



## BENEFITS & POINT OF DIFFERENCE

- Built-in Applying Sponge
- Leaves a Protective Film
- Biodegradable & Non-Toxic

## IDEAL FOR:

- Glass Cooktops
- Ceramic Glass
- Enamel Cooktops
- Induction Cooktops
- Shower Screens
- Ceramic Tiles

## HANDY HINT:

Use Magic Hotplate Restorer on solid/cast iron hotplates. Use Magic's Cooktop Cleaner & Protector after every time you cook and on shower screens to remove shower scum.

## Customer Reviews

*"The best & only product that cleans & protects your cooktop, making it look brand new! No scratches or markings! I wouldn't use any other product!"*

**-Helen D**

*"This product is amazing. Sorry I didn't discover it earlier"*

**-Barbara G**

Before

Induction Cooktop

After



Before

After

Glass Shower Screen

Before

After



FOR MORE INFORMATION CONTACT

1800 652 755

info@rubbedin.com.au

Rubbedin Pty Ltd

Unit 1, 43 Neumann Road, Capalaba, QLD 4157 Australia

[magiccleaningproducts.com.au](http://magiccleaningproducts.com.au)

@magiccleaningproducts

2023-7-CTOP-FS-01



SCAN ME